

Dry Ice Guide Table

Pounds of dry ice recommended for Frozen Packaging and Shipping. Extra dry ice is included to compensate for ambient room temperature containers, product and package conditioning prior to shipping.

Weight of Frozen Product	Time in Transit					
	24 Hour		2 Days		3 Days	
	Block Dry Ice	Snow Dry Ice	Block Dry Ice	Snow Dry Ice	Block Dry Ice	Snow Dry Ice
2 LB	5 LB	6 LB	10 LB	12 LB	15 LB	18 LB
5 LB	8 LB	9 LB	15 LB	17 LB	22 LB	25 LB
10 LB	10 LB	12 LB	20 LB	23 LB	30 LB	33 LB
20 LB	15 LB	17 LB	25 LB	28 LB	35 LB	39 LB
50 LB	20 LB	22 LB	30 LB	33 LB	45 LB	49 LB

* Test and verify with your company's packaging requirements.

* Dry ice snow must be pressed firmly down using hand protective gloves to slow sublimation.

To fill all void areas with solid packing material, reference HOW TO: Guidelines on Packaging Perishable Products.

Professional Packaging Assistance

Polar Tech Industries manufactures the largest selection of insulated containers and cold packs. You can rely on Polar Tech's consistent, quality service and proven packaging solutions. Since 1994, Polar Tech's thermal testing lab division has assisted companies that require validations or verification testing and support documentation for mandated records of compliant packaging performance and procedures. Our products are supplied by many distributors nationwide and in Canada. For your nationwide requirements, visit www.polar-tech.com, Videos: HOW TO: Guidelines on Packaging Perishables, Product FAQs.